



SKS Fiberforce Stock

Installation Instructions

PART# SKS3000, A.2.20.1290, A.2.40.1290

Thank you for purchasing an ATI product!

Advanced Technology
INTERNATIONAL



Stock Installation

INTRODUCTION

The ATI Strikeforce Stock will fit any of the SKS Models, including the 10rd, 30rd, and those models with 16" and 20" barrels. Please follow these instructions carefully to assemble the stock to your SKS. Some minor modifications may be necessary due to the many variations of the SKS. For most modifications, a rotary file tool or woodworking file will be the only tool necessary.

NOTICE: The SKS Strikeforce folding stock may be utilized on any SKS using folding stocks prior to November of 1990 or must have enough compliance parts to be legal as a folder; Assembly otherwise may be in violation of sec. 922(R). Note: Stock and Handguard are made in the USA and count towards compliance parts. **NOTE:** The blade bayonet **MUST** be removed or serious hand injury could occur. Inspect the rifle, magazine, and chamber to be sure the rifle is not loaded.

Point the rifle in a safe direction and place the safety in the "on" position. Next remove the magazine, pull back the bolt, and carefully inspect the chamber to be sure the rifle is unloaded.

Step #1

To remove the trigger assembly, first put the safety in the "on" position. Insert a pin punch or phillips head screwdriver into the spring latch catch at the rear of the trigger guard and press it inward firmly until the spring latch releases.



Figure 1

Step #2

The trigger assembly will now spring out, and can be removed from the stock by pulling, or prying outward on the rear of the receiver.



Figure 2

Step #3

The barrel action can now be removed by pulling outward and towards the rear.



Figure 3

Disclaimer: SKS Scope Mount, Cheekrest, and Soft Touch Cheekrest Pad are Sold Separately

Advanced Technology International • Made In the USA • Limited Lifetime Warranty
2733 West Carmen Ave • Milwaukee, WI 53209
Toll Free: 800.925.2522 • Fax: 414.464.3112

www.ATIGunstocks.com



SKS Fiberforce Stock

Installation Instructions

PART# SKS3000, A.2.20.1290, A.2.40.1290

Thank you for purchasing an ATI product!

Advanced Technology
INTERNATIONAL



Stock Installation

Step #4

Remove the existing Gas Tube Assembly from your SKS. Use a screwdriver or punch from your SKS cleaning kit to raise the lever on the right side of the rear sight base. The dimple on the lever should stop at the end of the curved track on the right side of the rear sight base.

Note: Further movement will cause the operating rod and spring to shoot out of the action.



Figure 4

Step #5

With the lever in this position you can now lift the gas tube assembly up and out of the gun. Pull upward at the rear of the gas tube assembly. This may require some careful prying with a screwdriver (Do not bend the gas tube). Next remove the gas piston from the assembly by tipping it upside down. It will simply slide out.



Figure 5

Step #6

There is a small rivet running crosswise through the rear handguard cover in the gas tube assembly. The rivet may be difficult to see. The rivet has two ends, the head and the shaft. Be sure to punch out from the shaft end. Remove this rivet by using a 1/16" punch or the "punch" provided in your cleaning kit. Eye protection is necessary.




Figure 6

Step #7

Once the rivet is removed, the rear sheet metal cover will slide off, as will the wooden handguard. If the rivet is damaged, a similar sized finished nail can be cut to length to serve as a replacement. To install the new handguard reverse steps 4 through 6.




Figure 7

Advanced Technology International • Made In the USA • Limited Lifetime Warranty

2733 West Carmen Ave • Milwaukee, WI 53209

Toll Free: 800.925.2522 • Fax: 414.464.3112

www.ATIGunstocks.com



SKS Fiberforce Stock

Installation Instructions

PART# SKS3000, A.2.20.1290, A.2.40.1290

Thank you for purchasing an ATI product!

Advanced Technology
INTERNATIONAL



Stock Installation

Step #9

To assemble the new stock to the barreled action, reverse the disassembly process.

Note: The forearm sides will install closely over the matching handguard. It may be necessary to use a thin bladed common screwdriver to guide the forearm sides into the handguard as the barreled action is being installed. Use of the trigger group kick-out spring from the original wood stock is NOT necessary or recommended.



Figure 9

Step #10

If you have difficulty reinstalling the magazine, make certain that the stock is as far forward on the action as it will go. The bolt must be locked back for the magazine to be installed. Make certain that the magazine front locator is in its mating slot on the bottom of the rear sight base, and install the magazine.



Figure 10

Step #11

To install the trigger group, place the barreled action/stock assembly inverted on a padded surface. Be sure the trigger group hammer is cocked and that the safety is in the "on" position. Align the front of the trigger group into the stock, making certain that the trigger group cross pin goes into the locator lugs on the receiver bottom. Push the rear of the trigger group down, until it stops.



Figure 11

Step #12

Push firmly down on the pistol grip, and tap the trigger guard down and forward with a padded hammer if necessary. Check to make sure that the trigger group is fully locked in place by moving the safety to the "off" position. If any unusual resistance is encountered, the trigger group is not fully latched. Tapping the trigger group downward while moving the safety lever to the "off" position usually completes the latching process.



Figure 12

Advanced Technology International • Made In the USA • Limited Lifetime Warranty

2733 West Carmen Ave • Milwaukee, WI 53209

Toll Free: 800.925.2522 • Fax: 414.464.3112

www.ATIGunstocks.com